

OPERATION OF THE TIMER

These instructions pertain to the mechanical "TORK" brand Timer.

Open the Timer compartment (there is a set of instructions inside of the door). Refer to figure below. Just below the Main Dial and to the right on the "TORK" label is a small triangle with the word "Time" printed on it. The Main Dial is divided into morning, afternoon, evening and night. Each graduation mark and silver ring represents 15 minutes. The figure below shows the time to be 12 o'clock noon.

To set: rotate the Main Dial counter-clockwise until the *present time* of day is adjacent to the small triangle.

To set the time for the Pump to operate, flip the desired silver ring to the center of the dial. In the figure below the Pump is set to operate at 8:30 in the morning and 4:30 in the afternoon. The Small Dial in the upper right hand corner of the Timer is used to determine the length of time the unit is to run. Running time can be set from 1 second to 90 seconds. 60 seconds is the optimum time for the insecticide to thoroughly cover the area. If the fly infestation is heavy, it is better to have the Unit operate more often during the day rather than lengthening the time for the Unit to operate. If the Unit is not to operate during a twenty-four hour period, push all the silver rings to the **outside** of the Dial. The system then can be operated by the Manual Over-Ride Switch. This is very convenient during the late Fall and early Spring. Times may vary. Refer to "Final Set Up" page 10 in the owners manual.

Note: If there is a power failure the Timer will have to be re-set.

